

Moisturising Hand Disinfectant

with ERYLITE® and Potassium Lactate



Recipe

Phase	Ingredients	INCI	Supplier	Quantity
A	Water, deionised	Aqua		Qs to 100 %
	ERYLITE®	Erythritol	Jungbunzlauer	2.0 %
	Potassium Lactate	Potassium Lactate	Jungbunzlauer	1.0 %
B	Ethanol	Alcohol	Sigma-Aldrich	63.0 %

Directions

- 1 Dissolve ingredients of phase A in the given order in water while stirring
- 2 Carefully add ethanol and stir for 30 minutes

Technical Data

Appearance: clear liquid

pH value: 7.3

Stability

Stable for 1 month at 4°C, 20°C and 40°C.

Headquarters **Jungbunzlauer Suisse AG** · CH-4002 Basel · Switzerland · Phone +41-61-2955 100

www.jungbunzlauer.com

Jungbunzlauer

*From nature
to ingredients®*