

## Natural peel-off clay mask

with Glucono-delta-Lactone



Phase	Ingredients	INCI	Supplier	Quantity
A	VIVASTAR® CS 022	Algin	J. Rettenmaier & Söhne	10.00 %
	ERYLITE® Personal Care Grade	Erythritol	Jungbunzlauer	15.00 %
	Tricalcium Citrate TB	Calcium Citrate	Jungbunzlauer	10.00 %
	Glucono-delta-Lactone Personal Care Grade F5010	Gluconolactone	Jungbunzlauer	10.00 %
	Rice starch	Oryza sativa (rice) starch	BENEO GmbH	20.00 %
	Kaolin Pharma	Kaolin	C.H. Erbslöh	32.00 %
B	CITROFOL® AI Extra	Triethyl Citrate	Jungbunzlauer	3.00 %

## Directions

- 1 Micronise ERYLITE®
- 2 Thoroughly blend all ingredients from phase A
- 3 Add phase B dropwise into phase A whilst stirring
- 4 For use, blend powder into tap water at a ratio of 1:2.5, stir thoroughly to obtain a homogeneous paste and immediately apply to face
- 5 Leave on for 10-15 min, then peel off the hardened mask and rinse the face with water

## Technical Data

Clay-coloured powder

pH of ready-to-use paste: 5.5

Appearance: clay-coloured powder

pH: 5.3 - 5.5 in ready-to-use paste

## Stability

Stable for at least 3 months at RT, 1 °C (34 °F) and 40 °C (104 °F)



---

Headquarters **Jungbunzlauer Suisse AG** · CH-4002 Basel · Switzerland · Phone +41-61-2955 100

For further information please contact: [headquarters@jungbunzlauer.com](mailto:headquarters@jungbunzlauer.com)

**[www.jungbunzlauer.com](http://www.jungbunzlauer.com)**

The information contained herein is meant to demonstrate how our products can be used. This formulation has been subjected to limited stability tests and has been shown to perform well. The given data are suggestions without any guarantee aimed to support customers' development.