

Jungbunzlauer

From nature to ingredients®



Remineralising tooth tabs

with ERYLITE®

Phase	Ingredients	INCI	Supplier	Quantity
A	ERYLITE® Stevia 200	Erythritol, Stevia Rebaudiana Extract	Jungbunzlauer	44.70 %
	Omyacare® S95-OG	Calcium Carbonate	Omya	20.00 %
	Hydroxypropylcellulose SSL-SFP	Hydroxypropyl-cellulose	NISSO CHEMICAL EUROPE	10.00 %
	Microcrystalline Cellulose 102	Microcrystalline Cellulose	DFE Pharma	6.00 %
	Omyadent® 100-OG	Hydroxyapatite (and) Calcium Carbonate	Omya	5.00 %
	BICAR® Food 0/13	Sodium Bicarbonate	Solvay	5.00 %
	Spearmint Flavour	Flavour	FREY + LAU	3.50 %
	Xanthan Gum FN OC	Xanthan Gum	Jungbunzlauer	1.50 %
	Primellose®	Croscarmellose Sodium	DFE Pharma	1.50 %
	Zinc Lactate Dihydrate	Zinc Lactate	Jungbunzlauer	1.00 %
	TEGO® Betain CK D	Cocamidopropyl Betaine	Evonik	1.00 %
B	Phoskudent® SF	Sodium Fluoride	BK Giulini	0.30 %
	Magnesium Stearate	Magnesium Stearate		0.50 %

Directions

- 1 Dry blend all ingredients of phase A
- 2 Add phase B to dry blend of phase A and mix with moderate speed
- 3 Press powder to tablets

Tableting parameter

Tablet press: FlexiTab®

Punch size: 9 mm

Fill depth: 10.4 mm

Force: 9 kN

Technical Data

Physical form: Tablets

Appearance: solid tablets, biconvex

Weight: 0.46 g / tablet

pH value: 8.0–8.5 (10 % solution with tap water at 20–25 °C)

Stability

Stable for at least 3 months at 30 °C (86 °F) and 50 % relative humidity with open storage



Headquarters **Jungbunzlauer Suisse AG** · CH-4002 Basel · Switzerland · Phone +41-61-2955 100

For further information please contact: headquarters@jungbunzlauer.com

www.jungbunzlauer.com

The information contained herein is meant to demonstrate how our products can be used. This formulation has been subjected to limited stability tests and has been shown to perform well. The given data are suggestions without any guarantee aimed to support customers' development.